

# ***AA/AAA Non-Rechargeable Battery Units*** **IMPORTANT SAFEGUARDS**

When using your electrical appliance, basic precautions should always be followed, including the following:

**READ ALL INSTRUCTIONS AND SAFEGUARDS BEFORE USING THIS APPLIANCE.**

## **WARNING**

**To reduce the risk of injury to persons:**

1. This appliance can be used by children aged from 14 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction, by a person responsible for their safety, concerning the use of the appliance in a safe way and understand the hazards involved. Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
2. Keep out of reach of children. Swallowing a battery can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.
3. Use this appliance only for its intended use as described in the manual. Do not use attachments not recommended by the manufacturer.
4. Do not use this appliance with parts or attachments that have been damaged or broken as injury may occur.
5. When discarding an old battery, do not throw it into fire where heat could cause it to rupture or explode. Also, do not attempt to recharge alkaline, heavy-duty, or lithium batteries in a battery charger. Remove the exhausted batteries from the appliance, and dispose properly.
6. Risk of fire and burns. Do not recharge, disassemble, or incinerate. Keep battery out of reach of children. Dispose of used batteries promptly.
7. Different types of batteries (alkaline, standard, rechargeable, etc.) or new and used batteries are not to be mixed.
8. If the appliance is to be stored unused for a long period, the batteries should be removed.
9. The battery terminals are not to be short-circuited.

## **SAVE THESE INSTRUCTIONS**

### **For Household Use Only**

***Our units are quality tested with hygienic fibers. Any residual fibers do not affect performance and can be brushed off.***

© 2024 Wahl Clipper Corporation  
art no. 1007872 (v.2024.02a)

## ***Unidades con Baterías AA/AAA No Recargables***

# **MEDIDAS DE SEGURIDAD IMPORTANTES**

Cuando use el artefacto eléctrico, siempre debe tener en cuenta precauciones de seguridad básicas, incluidas las siguientes:

**LEA TODAS LAS INSTRUCCIONES Y MEDIDAS DE SEGURIDAD ANTES DE USAR ESTE ARTEFACTO.**

## **ADVERTENCIA**

**Para reducir el riesgo de lesiones a personas:**

1. Este artefacto lo pueden usar niños de 14 años o mayores y personas con capacidades físicas, sensoriales o mentales reducidas, o sin experiencia y conocimiento, bajo la supervisión e instrucción de una persona responsable por su seguridad, respecto al uso seguro del artefacto y la comprensión de los peligros involucrados. Los niños deben ser supervisados para asegurarse que no jueguen con el aparato. Los niños no deben realizar la limpieza ni el mantenimiento sin supervisión.
2. Mantenga fuera del alcance de los niños. Tragar una batería puede provocar quemaduras químicas, perforación de tejidos blandos y la muerte. Pueden ocurrir quemaduras graves dentro de las 2 horas posteriores a la ingestión. Busque atención médica de inmediato.
3. Use este artefacto solo para su uso previsto, según se describe en el manual. No use accesorios no recomendados por el fabricante.
4. No use este aparato si tiene piezas o accesorios que se hayan dañado o roto, ya que podría provocar lesiones.
5. Cuando deseche una batería vieja, no la arroje al fuego ya que el calor puede causar ruptura o explosión. Tampoco intente recargar baterías alcalinas, de alto rendimiento o baterías de litio con un cargador para baterías. Saque las baterías agotadas del aparato y deséchelas correctamente.
6. Riesgo de incendio y quemaduras. No recargue, desarme o incinere. Mantenga la batería fuera del alcance de los niños. Deseche las baterías usadas inmediatamente.
7. No debe mezclar diferentes tipos de baterías (alcalinas, estándar, recargables, etc.), ni baterías nuevas con usadas.
8. Si va a almacenar el aparato sin usarlo por un período prolongado, debe sacarle las baterías.
9. Las terminales de la batería no deben conectarse en corto circuito.

## **GUARDE ESTAS INSTRUCCIONES**

### **Solo Para Uso Doméstico**

***Nuestras unidades pasan por pruebas de calidad con fibras higiénicas. Los residuos de fibras no afectan su rendimiento y pueden eliminarse con un cepillo.***