

# IMPORTANT SAFEGUARDS

When using your electrical appliance, basic precautions should always be followed, including the following:

**READ ALL INSTRUCTIONS AND SAFEGUARDS BEFORE USING THIS APPLIANCE.**

## DANGER

**To reduce the risk of death or injury by electric shock:**

1. Except when charging, always unplug the charger from the electrical outlet and from the appliance. The appliance will not operate (run) when plugged into the charger.
2. Always unplug this appliance before cleaning.

## WARNING

**To reduce the risk of burns, electrical shock or injury to persons:**

1. Do not crush, disassemble, heat above 100°C (212°F), or incinerate the appliance, due to risk of fire, explosion, or burns.
2. This appliance can be used by children aged from 14 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction, by a person responsible for their safety, concerning the use of the appliance in a safe way and understand the hazards involved. Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water. Return the appliance to Wahl Clipper Corporation for examination and

repair.

5. Keep the cord away from heated surfaces.
6. Do not use outdoors or operate while aerosol (spray) products are being used.
7. Never drop or insert any object into any opening.
8. Do not use this appliance with a damaged or broken comb nor with teeth missing from the blades, as injury may occur. Before use, make certain blades are aligned properly. (See Clipper Maintenance Instructions. May not be applicable for all appliances.)
9. During use, do not place or leave the appliance where it is expected to be subject to damage by an animal, or exposed to weather.
10. Always attach plug to appliance first, then to outlet.
11. To disconnect, turn all controls to "OFF" (e.g. "0"), then remove charger from outlet.
12. Turn all controls to "OFF" (e.g. "0"), before placing on or removing blades or attachments.
13. Use only the charger supplied by the manufacturer to recharge.
14. This charger is intended to be correctly orientated in a vertical or floor mount position.
15. Detach the hand-held part from the charger supply cord before cleaning it in water.

## SAVE THESE INSTRUCTIONS For Household Use Only



This symbol, located on the trimmer, represents that the shaver is suitable for use in the bath and shower.

## For Products Marked with an FCC Approval:

1. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.
3. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

# MEDIDAS DE SEGURIDAD IMPORTANTES

Cuando use el artefacto eléctrico, siempre debe tener en cuenta precauciones de seguridad básicas, incluidas las siguientes:

**LEA TODAS LAS INSTRUCCIONES Y MEDIDAS DE SEGURIDAD ANTES DE USAR ESTE ARTEFACTO.**

## PELIGRO

**Para reducir el riesgo de muerte o lesiones por descarga eléctrica:**

1. Excepto cuando se esté cargando, siempre desconecte el cargador del tomacorriente y del aparato. El aparato no funcionará mientras está conectado al cargador.
2. Siempre desenchufe este artefacto antes de limpiarlo.

## ADVERTENCIA

**Para reducir el riesgo de quemaduras, descargas eléctricas o lesiones a personas:**

1. No aplaste, desarme, caliente a más de 100 °C (212 °F) ni incinere el artefacto, debido al riesgo de incendio, explosión o quemaduras.
2. Este artefacto lo pueden usar niños de 14 años o mayores y personas con capacidades físicas, sensoriales o mentales reducidas, o sin experiencia y conocimiento, bajo la supervisión e instrucción de una persona responsable por su seguridad, respecto al uso seguro del artefacto y la comprensión de los peligros involucrados. Los niños deben ser supervisados para asegurarse que no jueguen con el aparato. Los niños no deben realizar la limpieza ni el mantenimiento sin supervisión.
3. Use este artefacto solo para su uso previsto, según se describe en este manual. No use accesorios no recomendados por el fabricante.
4. Nunca use este artefacto si tiene el cable o el enchufe dañado, si no funciona correctamente, si se ha caído o dañado o si se ha sumergido en agua. Lleve el artefacto a Wahl Clipper Corporation para su revisión y reparación.

5. Mantenga el cable alejado de superficies calientes.
6. No use al aire libre, ni mientras se usan productos en aerosol (rociadores).
7. Nunca deje caer ni inserte ningún objeto en ninguna abertura.
8. No utilice este artefacto con un peine dañado o roto ni con cuchillas a las que le falten dientes, ya que pueden provocar lesiones. Antes de usar, asegúrese de que las cuchillas estén bien alineadas. (Vea las Instrucciones de mantenimiento de la cortadora. Es posible que no apliquen para todos los artefactos).
9. Durante el uso, no coloque ni deje el artefacto en un lugar donde se supone que un animal pudiera dañarlo o expuesto al clima.
10. Siempre conecte primero el enchufe al aparato y luego al tomacorriente.
11. Para desconectarlo, gire todos los controles a la posición de APAGADO (por ejemplo, "0") y luego desconecte el cargador del tomacorriente.
12. Gire todos los controles a la posición de APAGADO (por ejemplo, "0") antes de poner o quitar cuchillas o accesorios.
13. Para recargarlo, use únicamente el cargador suministrado por el fabricante.
14. Este cargador está diseñado para orientarse correctamente en posición vertical o montado en el piso.
15. Desconecte la parte de mano del cable de alimentación del cargador antes de limpiarla con agua.

## GUARDE ESTAS INSTRUCCIONES Solo Para Uso Doméstico



Este símbolo, que se encuentra en la recortadora, indica que es apta para su uso en el baño y en la ducha.

## Para Productos Marcados con Aprobación de la FCC:



1. Este dispositivo cumple con la parte 15 de las Reglas de la FCC. Su operación está sujeta a las dos condiciones siguientes: (1) Este dispositivo no puede causar interferencia nociva, y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluyendo la interferencia que pueda causar una operación indeseada.
2. Los cambios y modificaciones que no sean aprobados explícitamente por la parte responsable del cumplimiento podrían anular la autorización del usuario para usar este dispositivo.
3. **NOTA:** Este equipo ha sido probado y se ha determinado que cumple con los límites de un dispositivo digital de Clase B, en los términos de la parte 15 de las Reglas de la FCC. Estos límites están diseñados para brindar una protección razonable contra la interferencia nociva en una instalación residencial. Este equipo genera, utiliza y puede emitir energía de radiofrecuencia y, de no instalarse y usarse de acuerdo con las instrucciones, puede causar interferencia nociva a las radiocomunicaciones. Sin embargo, no hay garantía de que no ocurrirá interferencia en una instalación en particular. Si este equipo causa interferencia nociva a la recepción de radio o televisión, lo que puede determinarse al encender y apagar el equipo, se invita al usuario a tratar de corregir la interferencia tomando una o más de las siguientes medidas:
  - Reorientar o reubicar la antena de recepción.
  - Aumentar la separación entre el equipo y el receptor.
  - Conectar el equipo a un tomacorriente que esté en un circuito diferente a aquel en el que está conectado el receptor.
  - Consultar a su distribuidor o a un técnico experimentado de radio y televisión.