

## **Quick Start Guide**

## **Keep it Running Like New!**

The blades of your new clipper should be oiled every few haircuts. For best results, place three drops on front of the blades and one drop on each side of blade as shown. Use only the Wahl Clipper Oil included in the pack. Do not use hair oil, grease or any oil mixed with kerosene or any solvent.



## **Your New Clipper**



## Goof- Proof!

## **Adding Attachment Guards**

Align guard onto blade then press down on guard where guard number is located until you hear a snap.






Removing Attachment Guards


From underneath, lift tab up to release from blade.

# Blend it!

Use for blending between different hair lengths. The taper lever adds versatility to your clipper by allowing you to gradually change the closeness of your cut. (Up position = closest cut; Down position = longest cut)



## You can do it!



### **Haircutting Tips & Techniques**

When you cut your hair, you should visualize the head as if it were divided into four sections. Image above shows the different sections. Using proper techniques when moving from one section to the next will help you blend the sections together for professional looking results. See instruction book for more tips.



## It's Easy!

Easy step-by-step instructions included. For more haircutting tips and techniques visit grooming.wahl.com.



# Thank You!

Thank you for purchasing this Wahl haircutting kit. We appreciate your support and we hope you enjoy your new clipper!

If you have any questions, please contact one of our USA based customer service representatives located next to our factory in Sterling, IL USA

www.grooming.wahl.com 1-800-767-9245



The Brand Used By Professionals

**Quick Start Guide** 

